
Local Console
Terminal Server or Modem
To Local Console
DB-9
DB-25
To Terminal Server or Modem
RS-232
RS-232
DB-9
DB-9
To Craft 2 Port on Controller Card
FAIL
ACTIVE
STDBY
SYNC
XCRP SD-1
EXT TIMING LOS
SEC
PRI
COMPACT FLASH TYPE II
CF ACTIVE
CRAFT 2
CRAFT 1
LINK/ ACTIVITY
SPEED
ENET
0692